



1

Thread the soft-link through the loop on the paraglider's risers and the first hole in the elastic sleeve, then through the loops on the main lines.



2

Thread the narrow end of the soft-link through the second hole in the elastic sleeve.



3

Pass through the loop on the risers again.



4

... and the first hole in the elastic sleeve.



5

Pass through the loops on the main lines again.



6

Thread the soft-link through the second hole in the elastic sleeve once more.



7

Important: Pass the narrow end of the soft-link through the loop on its other end, where the black pin is located.



8

Place the loop of the soft-link onto the black pin after.



9

Tighten the loop and tension the soft-link from both sides.



10

Insert the black pin into the second hole in the elastic sleeve. The pin should be directed towards the canopy of the paraglider.